



When creating a corner with ProGuard use Water Armor TG to cover the mitered corner in a 1/16" thick skim coat and immediately center and embed Water Armor Flash Tape into the wet skim coat.