



When creating a corner with ProGuard using self-adhering mesh tape, apply the tape centered over the mitered corner. Then cover over the tape with a skim coating of Water Armor TG.