



If the cement backer board meets flush with the connecting backing board and there is a gap between the foam, use expanding foam such as Fomo, or a similar polystyrene compatible expanding foam, to fill the area. Make sure to smooth the excess foam to be flush with the foam side.

